



- 1** The cut-out for the skylight must be 400 x 400 mm.
- 2** Place the skylight in the recess and make sure that the hole is large enough. Ensure that the hinges are pointing towards the front of the motor home or caravan.
- 3** If the skylight fits, thoroughly clean the contact points between the skylight and the roof of the motor home or caravan before installation.
- 4** Place a generous amount of the correct sealant around the edge of the skylight, and position the skylight in the recess.
- 5** Place the provided clips in the slots of the skylight and use the provided screws depending on the thickness of your roof.
- 6** Now place the internal frame and fix it with the supplied screws. **CAUTION:** Tightening these screws too tightly may cause the skylight to move. If the window is unbolted this may affect its function.
- 7** Now place the cover caps to conceal the screws of the internal frame.

NOTE: If you have problems understanding the installation instructions, please contact a specialist immediately. Screws are included.

CAUTION: Do not overtighten the screws, and tighten them crosswise.